

Technical Datasheet

Create Date: 16.11.2017 - Seite 1/

Leak Detection



non-flammable non-corrosive does not cause skin irritation and DIN-DVGW-tested

The agent is used for the fast, convenient and reliable location of leaks (cracks or porous spots) in pressurized pipes.

WEICON Leak Detection does not form any hazardous compounds with carbon dioxide (CO2), propane, butane, acetylene, oxygen, city or natural gases.

WEICON Leak Detection can be used wherever compressed air, natural or liquid gas is processed, and wherever leaky points can occur on fittings, threated joints, and connections. It greatly contributes to the safety of pneumatic brakes and gas lines.

Technical Data

| Odour | | almost odourless |
|------------------------|----------------------------|--|
| Shelf life min. | | 24 months |
| Features | approved for gas piping by | German DVGW, suitable for oxygen and CO# |
| Colour | | milky |
| Temperature resistance | | to +50 °C |
| Suitable for use with | | WSD 400 and WPS 1500 |
| IMPA-Code | | 58 16 31/32/33 |

Processing

Shake Leak Detector prior to use resp. prior to refilling into pressure container (4-6 bar, e.g. into Air Pressure Can). Richly apply with a brush or by spraying onto the area to be tested. Bubbles will be formed if there is a leakage. Avoid contact with eyes. Rinse splashes with water.

Storage

Keep in closed original container. Protect from direct solar radiation. Storage temperature may not exceed +50°C. Store container at cool and aired place. Store in a dry place.

Safety and health

When using WEICON products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

Available sizes:

 15400005
 Leak Detection 5 L

 15400010
 Leak Detection 10 L

 15400030
 Leak Detection 30 L

Accessories:

11850200 Hand Protective Foam, 200 ml 15810001 Adapter for WSD 400, 15811002 Spray-Valve set for WSD 400, 15811400 Pressurized-Air Spray Can WSD 400, 15830001 Adjusting Valve for cans, 5/10 L Pump-Dispenser WPS 1500, 15841500 Extension for WPS 1500, 15841501 15842001 Pump Dispenser, Standard 15843001 Pump Dispenser Special,

Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON GmbH & Co. KG (Headquarters) Germany phone +49 (0) 251 9322 0 info@weicon.de

WEICON SA (Pty) Ltd South Africa phone +27 (0) 21 709 0088 info@weicon.co.za WEICON Middle East L.L.C. United Arab Emirates phone +971 4 880 25 05

WEICON South East Asia Pte Ltd Singapore phone (+65) 6710 7671 WEICON Inc.
Canada
phone +1 877 620 8889
info@weicon.ca

WEICON Czech Republic s.r.o. Czech Republic phone +42 (0) 417 533 013 WEICON Kimya Sanayi Tic. Ltd. Şti. Turkey phone +90 (0) 212 465 33 65 info@weicon.com.tr

WEICON Ibérica S.L. Spain phone +34 (0) 914 7997 34 WEICON Romania SRL Romania phone +40 (0) 3 65 730 763 office@weicon.com