

#### **Technical Datasheet**

Create Date: 17 11 2017 - Seite 1/

## **Parts and Assembly Cleaner**



# specially developed cleaner with a high flash point (> +60°C/ +140°F of the agent)

WEICON Parts and Assembly Cleaner is a specially developed cleaner with a high flashpoint (> +60°C/+140°F of the active ingredient) and a long working time for the removal of coarse, oily, resinified and greasy contamination.

Due to its high flashpoint, WEICON Parts and Assembly Cleaner conforms to the former VbF classification AIII (VbF = Regulation concerning flammable liquids) and complies with the recommendations of the professional associations for safety at work.

It quickly and thoroughly cleans all kinds of assembly parts, aggregates, construction parts and tools. It removes oils, greases, dirt, etc., from all metal parts and cleans brakes, clutches, engine parts, etc. in the automotive sector.

### **Technical Data**

Odour	solvent
Shelf life min.	12 months
Features	high flash point (> +60°C)
Colour	colourless
Suitable for use with	WSD 400 and WPS 1500
ISSA-Code	53.402.56/57/58
IMPA-Code	55 15 74/75/76

#### **Processing**

Spray a sufficient quantity onto the parts to be cleaned and allow to react. If necessary, wipe off with a clean cloth. Repeat this process with heavy soiling.

#### Storage

Keep in closed original container. Protect from direct solar radiation. Storage temperature may not exceed +50°C. Store container at cool and aired place. Store in a dry place.

#### Safety and health

When using WEICON products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

#### Available sizes:

15211005	Parts and Assembly Cleaner 5 L
15211010	Parts and Assembly Cleaner 10 L
15211030	Parts and Assembly Cleaner 30 L

#### Accessories:

11850200	Hand Protective Foam, 200 ml
15810001	Adapter for WSD 400,
15811002	Spray-Valve set for WSD 400,
15811400	Pressurized-Air Spray Can WSD 400,
15830001	Adjusting Valve for cans, 5/10 L
15841500	Pump-Dispenser WPS 1500,
15841501	Extension for WPS 1500,
15842001	Pump Dispenser, Standard
15843001	Pump Dispenser Special,

#### Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON GmbH & Co. KG (Headquarters) Germany phone +49 (0) 251 9322 0 info@weicon.de

WEICON SA (Pty) Ltd South Africa phone +27 (0) 21 709 0088 info@weicon.co.za WEICON Middle East L.L.C. United Arab Emirates phone +971 4 880 25 05

WEICON South East Asia Pte Ltd Singapore phone (+65) 6710 7671 info@weicon.com.sg WEICON Inc.
Canada
phone +1 877 620 8889
info@weicon.ca

WEICON Czech Republic s.r.o. Czech Republic phone +42 (0) 417 533 013 WEICON Kimya Sanayi Tic. Ltd. Şti. Turkey phone +90 (0) 212 465 33 65 info@weicon.com.tr

WEICON Ibérica S.L. Spain phone +34 (0) 914 7997 34 info@weicon es WEICON Romania SRL Romania phone +40 (0) 3 65 730 763 office@weicon.com